


G1-Yttre - 41 plasser

19 plasser	Dør	Port	22 plasser
(H01) 01	G1- Y		(V01) 02
(H02) 03			(V02) 04
(H03) 05			(V03) 06
(H04) 07			(V04) 08
(H05) 09			(V05) 10
(H06) 11			(V06) 12
(H07) 13			(V07) 14
(H08) 15			(V08) 16
(H09) 17			(V09) 18
(H10) 19			(V10) 20
(H11) 21			(V11) 22
(H12) 23			(V12) 24
(H13) 25			(V13) 26
(H14) 27			(V14) 28
(H15) 29			(V15) 30
(H16) 31			(V16) 32
(H17) 33			(V17) 34
(H18) 35			(V18) 36
(H19) 37			(V19) 38
	(V20) 40		
	(V21) 42		
	(V22) 44A		
			
	Brann port	Teknisk rom	

G1-Indre - 38 plasser

16 plasser	Brann port	22 plasser
(H01) 39	G1- I	(V01) 44B
(H02) 41		(V02) 44C
(H03) 43		(V03) 44D
(H04) 45		(V04) 44E
(H05) 47		(V06) 46
(H06) 49		(V07) 48
(H07) 51		(V08) 50
(H08) 53		(V09) 52
(H09) 55		(V10) 71
(H10) 57		(V11) 73
(H11) 59		(V12) 75
(H12) 61		(V13) 77
(H13) 63		(V14) 79
(H14) 54		(V15) 81
(H15) 67		(V16) 83
(H16) 69		(V17) 85
	(V18) 87	
	(V19) 89	
	(V20) 91	
	(V21) 93	
	(V22) 95	

